

## CS700-1 Signal Generator. V1.1

To be fitted at an anti-static work station while wearing anti-static protection.

1. Remove the two Philips screws from underside of Cleverscope Acquisition Unit. Remove top cover.
2. Fit CS700-1 signal generator board by carefully pushing BNC through rear hole. Seat the circuit board on the two plastic pillars , using a pair of long nosed pliers to help move the right rear plastic mounting pillar into place. Set the frontward part of the circuit board onto the plastic pillars and press firmly home.
3. Replace the top cover, and screws.
4. Carry out a signal generator calibration using Settings/Calibrate Cleverscope/Signal Generator, following the instructions on the panel.